

Replacement Sheet

FIG. 2A


IMMEDIATELY AFTER
SUCKING SALT WATER

FIG. 2B


CHANGE SALT INTO
SALT WATER BY
DELIQUESCENT

FIG. 2C


IMMEDIATELY AFTER
AIR SUCTION BY
CRANKING ETC.

FIG. 2D



CURRENT SUPPLY TO
HEATING RESISTOR


FIG. 3




Replacement Sheet

FIG. 4A


IMMEDIATELY
AFTER SUCKING
SALT WATER

**FIG. 4B**


CHANGE SALT INTO
SALT WATER BY
DELIQUESCENT

**FIG. 4C**

CURRENT SUPPLY
TO HEATING
RESISTOR

**FIG. 4D**

IMMEDIATELY
AFTER AIR
SUCTION BY
CRANKING ETC.



Replacement Sheet

FIG. 5




FIG. 6

